

MITAC PD10BI



BIOS settings notes + Fix display problems

When having boot problems you can fix them by setting the correct OS type in BIOS.


Enter BIOS by pressing „DEL“ button at boot time.

Go to section „Save & Exit“


Choose your OS and confirm with „Enter“ button.



Go to section „Chipset“ and choose „Output Panel Type“.





If you didn't installed your OS by UEFI then set this key to „eDP“.




Save settings with „F4“ button.

No display output problem

„Clear CMOS“ by setting jumper below to “Clear CMOS” position and back.





The system now should show display output again.

02.07.2014, CarTFT.com